

目錄 TABLE OF CONTENTS

序號	名稱	頁次
Ref. No.	Description	Page Number
1	Ct9611 本體與外裝零件(一) Frame Components(一) For CT9611-----	1
2	CT9611 本體與外裝零件(二) Frame Components For(二) CT9611-----	3
3	CT9611 導針與張力調整零件 Thread Guide And Tension Components For Ct9611-----	5
4	CT9611 軸襯與油封 Bushing And Seal For Ct9611 -----	9
5	CT9611 下軸與相關零件 Lower Main Shaft Components For Ct9611 -----	11
6	CT9000/CT9611上軸與相關零件 Upper Main Shaft Components For CT9000/CT9611-----	13
7	CT9611/CTD9611 針棒與相關零件 Needle Bar Components For CT9611/CTD9611-----	15
8	CT9000/CT9611 壓腳與相關零件 Presser Foot Components For Ct9000/CT9611-----	17
9	CT9000/CT9611/CTD9000/CTD9611 裝飾線驅動機構 Spreader Mechanism For CT9000/CT9611/CTD9000/CTD9611-----	19
10	CT9611/CTD9611/ CTF9611 結線鉤驅動機構 Looper Driving Mechanism For CT9611/CTD9611/ CTF9611-----	21
11	CT9611/CTD9611 進給變換機構 Feed Control Driving For CT9611/CTD9611 -----	23
12	CT9611/CTD9611 導針與送布齒驅動機構 Needle Guide And Feed Dog Driving For CT9611/CTD9611 -----	27
13	CT9611 潤滑系統 Lubrication System For CT9611-----	29
14	66707 線架Thread Stand 66707 -----	33
15	CT9611 裝載附件 Supporting Board For CT9611-----	35
16	CT9611 工具及附件 Accesseries For Ct9611-----	37
17	車型定規列表Gauge Parts List -----	39