

# 目錄 TABLE OF CONTENTS

序號	名稱	頁次
Ref. No.	Description	Page No.
1	CTD9000 本體與外裝零件Frame Components For CTD9000 (一) -----	1
2	CTD9000 本體與外裝零件Frame Components For CTD9000 (二) -----	3
3	CTD9000 導針與張力調整零件Thread Guide And Tension Components For CTD9000 -----	5
4	CTD9000 軸襯與油封Bushing And Seal For CTD9000 -----	9
5	下軸與相關零件 Lower Main Shaft Components -----	11
6	上軸與相關零件 Upper Main Shaft Components -----	13
7	針棒與相關零件 Needle Bar Components -----	15
8	壓腳與相關零件 Presser Foot Components -----	17
9	裝飾線驅動機構 Spreader Mechanism -----	19
10	結線鉤驅動機構 Looper Driving Mechanism -----	21
11	進給變換機構 Feed Control Driving -----	23
12	導針與送布齒驅動機構 Needle Guide And Feed Dog Driving -----	25
13	潤滑系統 Lubrication System -----	29
14	66707 線架 Thread Stand 66707 -----	33
15	裝載附件 Supporting Board -----	35
16	工具及附件 Accesseries -----	37
17	車型定規列表 Gauge Parts List -----	39