

目錄 TABLE OF CONTENTS

序號	名稱	頁次
Ref. No.	Description	Page No.
1	CTD9611 本體與外裝零件Frame Components For CTD9611 (一)-----	1
2	CTD9611 本體與外裝零件Frame Components For CTD9611 (二)-----	3
3	CTD9611 導針與張力調整零件Thread Guide And Tension Components For CTD9611 -----	5
4	CTD9611 軸襯與油封Bushing And Seal For CTD9611 -----	9
5	CTD9611 下軸與相關零件Lower Main Shaft Components For CTD9611 -----	11
6	CTD9000 /CTD9611 上軸與相關零件Upper Main Shaft Components For CTD9000 /CTD9611 -----	13
7	CT9611/CTD9611 針棒與相關零件 Needle Bar Components For CT9611/CTD9611-----	15
8	CTD9000/CTD9611 壓腳與相關零件Presser Foot Components For CTD9000/CTD9611-----	17
9	CT9000/CT9611/CTD9000/CTD9611 裝飾線驅動機構 Spreader Mechanism For Ct9000/CT9611/CTD9000/CTD9611-----	19
10	CT9611/CTD9611 結線鉤驅動機構 Looper Driving Mechanism For CT9611/CTD9611-----	21
11	CT9611/CTD9611 進給變換機構 Feed Control Driving For CT9611/CTD9611 -----	23
12	CT9611/CTD9611 導針與送布齒驅動機構 Needle Guide And Feed Dog Driving For CT9611/CTD9611 -----	27
13	CTD9611 潤滑系統Lubrication System For CTD9611-----	29
14	66707 線架 Thread Stand 66707 -----	33
15	CTD9611 裝載附件Supporting Board For CTD9611-----	35
16	CTD9611 工具及附件Accesseries For CtD9611-----	37
17	車型定規列表 Gauge Parts List -----	39