

CTF9011-0-0 □□□ M
 CTF9011-0-□□□ M

CTF9011 GAUGE PARTS LIST












Main Parts 更換 機 零件 型 針 Models 距 m.m	Throat plate 針板	Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針	
												5220FD00563
3	4.8	5220TP00484	5227PFT00480	5220DG0016	5227DGT00560	5220NC00485	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #11	
3	5.6	5220TP00564	5227PFT00560	5220FD00563		5220DF00560						5220NC00561
3	6.4	5220TP00642	5227PFT00640	5220FD00643		5220DF00640						5220NC00641

CTF9011-0-0 □□□ H
 CTF9011-0-□□□ H












Main Parts 更換 機 零件 型 針 Models 距 m.m	Throat plate 針板	Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針	
												5220FD00563
3	4.8	5222TP00480	5227PFT00480	5220DG0016	5227DGT00560	5220NC00485	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #14	
3	5.6	5220TP00566	5227PFT00560	5220FD00563		5220DF00560						5220NC00561
3	6.4	5220TP00644	5227PFT00640	5220FD00643		5220DF00640						5220NC00641

CTF9011-0-0 □□□ W
 CTF9011-0- □□□ W

CTF9011 GAUGE PARTS LIST

Main Parts 更換 機 型 Models	針 距 m.m	零件 Throat plate 針板 	Presser foot asm 壓腳 	Main feed dog 主送布齒 	Diff feed dog 副送布齒 	Top feed dog 上送布齒 	Needle clamp 針留 	Upper looper 上結線勾 	Lower looper 下結線勾 	Needle guide 前導針 	Needle guide 後導針 	Needle 針 
3	6.4	5220TP00646	5227PFT00640	5220FD00643 5220DG0017	5220DF00640		5220NC00641					

CTF9011-0-0 □□□ L
 CTF9011-0- □□□ L

Main Parts 更換 機 型 Models	針 距 m.m	零件 Throat plate 針板 	Presser foot asm 壓腳 	Main feed dog 主送布齒 	Diff feed dog 副送布齒 	Top feed dog 上送布齒 	Needle clamp 針留 	Upper looper 上結線勾 	Lower looper 下結線勾 	Needle guide 前導針 	Needle guide 後導針 	Needle 針 
3	5.6	5222TP00560	5227PFT00560	5220FD00563 5220DG0016	5220DF00560		5220NC00561					
3	6.4	5222TP00640	5227PFT00640	5220FD00643 5220DG0017	5220DF00640		5220NC00641					

CTF9011-0-0 □□□ S
 CTF9011-0- □□□ S

CTF9011 GAUGE PARTS LIST

Main Parts 更換 機 零件 型 針 Models 距 m.m	Throat plate 針板	Stitch plate Tongue 針板舌	Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Aux feed dog 輔助送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針
3	4.8	5222TP00483			5222DG0010								
3	5.6	5222TP0056B	5222TPL156A	5227PFT00560	5222FD00560	5222DF00560	5222AF00560						UY128GAS #11
		5222TP00563			5222DG0010			5222NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	
3	6.4	5222TP0056B	5222TPL164A	5227PFT00640	5222FD00560	5222DF00560	5222AF00560						
		5222TP00643			5222DG0010			5222NC00641					

CTF9011-0-0 □□□ S1
 CTF9011-0- □□□ S1

Main Parts 更換 機 零件 型 針 Models 距 m.m	Throat plate 針板	Stitch plate Tongue 針板舌	Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Aux feed dog 輔助送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針
3	4.8	5222TP00484			5222DG0010								
3	5.6	5222TP0056B	5222TPL156C	5227PFT00560	5222FD00560	5222DF00560	5222AF00560						UY128GAS #11
		5222TP00564			5222DG0010			5222NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	
3	6.4	5222TP0056B	5222TPL164C	5227PFT00640	5222FD00560	5222DF00560	5222AF00560						
		5222TP00644			5222DG0010			5222NC00641					

CTF9200-0-0 □□□H
 CTF9200-0- □□□H

CTF9200 / CTF9311 GAUGE PARTS LIST

Main Parts 更換 機 型 Models	針 距 m.m	零件 Throat plate 針板	Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針
3	5.6	5220TP00567	5227PFT00560	5220FD00565 5220DG0024	5220DF00561	5227DGT00560	5220NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #14
3	6.4	5220TP00645	5227PFT00640	5220FD00565 5220DG0024	5220DF00561		5220NC00641					

CTF9311-0-0 □□□M
 CTF9311-0- □□□M

Main Parts 更換 機 型 Models	針 距 m.m	零件 Throat plate 針板	Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針
3	5.6	5222TPL1560	5227PFTL1560	5220FDL1561 5220DG0012	5220DFL1561	5227DGTL1560	5220NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #11
3	6.4	5222TPL1640	5227PFTL1640	5220FDL1561 5220DG0012	5220DFL1561		5220NC00641					

CTF9311-0-0 □□□S
 CTF9311-0- □□□S

CTF9311 GAUGE PARTS LIST












機 型 Models	針 距 m.m	Main Parts 更換 零件		Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針
		Throat plate 針板	Stitch plate Tongue 針板舌										
3	5.6	5222TPL156B 5222TPL1562	5222TPL156A	5227PFTL1560	5222FDL1560 5222DG0009	5222DFL1560	5227DGTL1560	5220NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #11
3	6.4	5222TPL156B 5222TPL1642	5222TPL164A	5227PFTL1640	5222FDL1560 5222DG0009	5222DFL1560		5220NC00641					

CTF9311-0-0 □□□S1
 CTF9311-0- □□□S1

機 型 Models	針 距 m.m	Main Parts 更換 零件		Presser foot asm 壓腳	Main feed dog 主送布齒	Diff feed dog 副送布齒	Top feed dog 上送布齒	Needle clamp 針留	Upper looper 上結線勾	Lower looper 下結線勾	Needle guide 前導針	Needle guide 後導針	Needle 針
		Throat plate 針板	Stitch plate Tongue 針板舌										
3	5.6	5222TPL156B 5222TPL1563	5222TPL156C	5227PFTL1560	5222FDL1560 5222DG0009	5222DFL1560	5227DGTL1560	5220NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #11
3	6.4	5222TPL156B 5222TPL1643	5222TPL164C	5227PFTL1640	5222FDL1560 5222DG0009	5222DFL1560		5220NC00641					

CTF9311-0-0 □□□ H
 CTF9311-0-□□□ H

CTF9311 GAUGE PARTS LIST

Main Parts 更換 機 零件 型 針 Models 距 m.m	 Throat plate 針板	 Presser foot asm 壓腳	 Main feed dog 主送布齒	 Diff feed dog 副送布齒	 Top feed dog 上送布齒	 Needle clamp 針留	 Upper looper 上結線勾	 Lower looper 下結線勾	 Needle guide 前導針	 Needle guide 後導針	 Needle 針	
												5222TPL1560
3	5.6	5222TPL1560	5222PFTL1560	5227FDL1561 5227DG0004	5220DFL1561	5227DGTL1560	5220NC00561	5220SL00560	5220LL00560	5220NG00563	5220NG00562	UY128GAS #11
3	6.4	5222TPL1640	5222PFTL1640	5227FDL1561 5227DG0004	5220DFL1561							