

目錄 TABLE OF CONTENTS

序號	名稱	頁次
Ref. No.	Description	Page Number
1	CTF9611 本體與外裝零件Frame Components For CTF9611(一)-----	1
2	CTF9611 本體與外裝零件Frame Components For CTF9611 (二)-----	3
3	CTF9611 導針與張力調整零件 Thread Guide And Tension Components For CTF9611 -----	5
4	CTF9611 軸襯與油封 Bushing And Seal For CTF9611 -----	9
5	CT9611 / CTF9611 下軸與相關零件Lower Main Shaft Components CT9611 / CTF9611 -----	11
6	CTF9011 / CTF9611 上軸與相關零件 Upper Main Shaft Components -----	13
7	CTF9011 / CTF9611 針棒與相關零件Needle Bar Components -----	15
8	CTF9011 / CTF9611 壓腳與相關零件Presser Foot Components -----	17
9	CTF9011 / CTF9611 裝飾線驅動機構 Spreader Mechanism -----	19
10	CT9611 / CTD9611 / CTF9611 結線鉤驅動機構 Looper Driving Mechanism -----	21
11	CT9611 / CTD9611 / CTF9611 進給變換機構Feed Control Driving -----	23
12	CT9611 / CTD9611 / CTF9611 導針與送布齒驅動機構 Needle Guide And Feed Dog Driving For CT9611 / CTD9611 / CTF9611 -----	27
13	CTF9611 潤滑系統Lubrication System For CTF9611 -----	29
14	CTF9011 / CTF9611 上送機構 Top Feed Mechanism For CTF9011 / CTF9611 -----	31
15	CT9611 / CTF9611 裝載附件 Supporting Board For CT9611 / CTF9611 -----	35
16	CTF9611 工具及附件 Accesseries For CTF9611 -----	39
17	66707 線架Thread Stand 66707 -----	41
18	車型定規列表Gauge Parts List -----	43