

目錄 TABLE OF CONTENTS

序號	名稱	頁次
Ref. No.	Description	Page Number
1	FT7000 本體與外裝零件 Frame And Cover For FT7000 (A) -----	1
2	FT7000 本體與外裝零件 Frame And Cover For FT7000 (B) -----	3
3	FT7000 導針與張力調整零件 Thread Guide And Tension Components For FT7000 -----	7
4	軸襯與油封Bushing And Oil Seal -----	11
5	FT7000 下軸與相關零件 Lower Main Shaft Components For FT7000 -----	13
6	FT7000 上軸與相關零件Upper Main Shaft Components For FT7000 -----	17
7	FT7000 / FTD7000 針棒與相關零件 Needle Bar Components For FT7000 / FTD7000 -----	19
8	FT7000 壓腳與相關零件 Presser Foot Components For FT7000 -----	21
9	FT7000 / FTD7000 裝飾線驅動機構 Spreader Mechanism For FT7000 / FTD7000 -----	23
10	FT7000 / FTD7000 結線鉤驅動機構 Looper Mechanism For FT7000 / FTD7000 -----	25
11	FT7000 / FTD7000 進給變換機構 Feed Mechanism For FT7000 / FTD7000 -----	27
12	FT7000 / FTD7000 導針與送布齒驅動機構 Needle Guide And Feed Dog Driving For FT7000 / FTD7000 -----	29
13	FT7000 潤滑系統 Lubrication System For FT7000 -----	31
14	66707 線架 Thread Stand 66707 -----	35
15	FT7000 裝載附件 Supporting Board For FT7000 -----	37
16	工具及附件 Accesseries -----	39
17	車型定規列表 Gauge Parts List -----	41