

目錄 TABLE OF CONTENTS

序號	名稱	頁次
Ref. No.	Description	Page Number
1	FTD7000 本體與外裝零件(一) Frame Components For FTD7000(一)-----	1
2	FTD7000 本體與外裝零件(二) Frame Components For FTD7000(二) -----	3
3	FTD7000 導針與張力調整零件 Thread Guide And Tension Components For FTD7000-----	7
4	FTD7000 軸襯與油封 Bushing And Seal For FTD7000-----	9
5	FTD7000 下軸與相關零件 Lower Main Shaft Components For FTD7000 -----	11
6	FTD7000上軸與相關零件Upper Main Shaft Components For FTD7000 -----	15
7	FT7000 / FTD7000 針棒與相關零件 Needle Bar Components For FT7000 / FTD7000 -----	17
8	FTD7000 壓腳與相關零件Presser Foot Mechanism For FTD7000-----	19
9	FT7000 / FTD7000 裝飾線驅動機構Spreader Mechanism For Ft7000 / FTD7000-----	21
10	FT7000 / FTD7000 結線鉤驅動機構Looper Mechanism For FT7000 / FTD7000 -----	23
11	FT7000 / FTD7000 進給變換機構Feed Mechanism For FT7000 / FTD7000 -----	25
12	FT7000 / FTD7000 導針與送布齒驅動機構Needle Guide And Feed Driving For FT7000 / FTD7000-----	27
13	FTD7000潤滑系統Lubrication Mechanism For FTD7000-----	29
14	66707 線架Thread Stand 66707 -----	33
15	FTD7000 裝載附件 Supporting Board For FTD7000-----	35
16	FTD7000 工具及附件Accesseries For FTD7000 -----	37
17	車型定規列表Gauge Parts List -----	39